

# Rate Map

1 Copy

5 Import

8 Save Image

10 Enable VR


13 Full Screen

14 Zones

15 Sat View


16 Rate Data

Zone


2 


3

4 0.0

6 

7

9 


11 

12 Color

Product A	<input type="text" value="0"/>
Product B	<input type="text" value="0"/>
Product C	<input type="text" value="0"/>
Product D	<input type="text" value="0"/>

^

v



©2025 Microsoft Corporation, ©2025 NAVTEQ, ©2025 Image courtesy of NASA

1. Copy rate map from another job.
2. Edit rate zone.
3. Name of zone.
4. Area of zone in acres or hectares.
5. Import
  - Press the Import button to open the Import form. Load an alternative type of shape file using the up-arrow on the Import form. The form will list the RC attributes on the left. Use the drop-down box to the right of each RC attribute to cross reference from the alternative file attributes. Use the down-arrow on the Import form to save a new RC shape file with these cross referenced attributes.
6. Edit polygons.
7. Product rates.
8. Save an image of the map to file.
9. Delete zone.
10. Enable VR
  - Enable variable rate control. Each product uses variable rate control. All zones must define a rate for each product used.
11. Save zone edits.
12. Zone color.
13. Full screen view.
14. Show zones overlay.
15. Show satellite view.
16. Show rate data overlay.