

## **Switches**

### 1. On-Screen Switches

- Display on-screen switches.

### 2. On-Screen Dual Auto

- Display separate switches for auto rate and auto section control.

### 3. Work Switch

- Use a switch connected to the implement to control On/Off.

### 4. Auto Switch Rate + Sections

- Auto rate control and auto section control.

### 5. Auto Switch Sections

- Auto section control only.

### 6. Master Override

- Lock the master switch to on.

## **Switch List:**

### 1. Switch number

- (1-16)

### 2. Description

- On-Screen name for the switch.

### 3. Module

- The number of the module containing the relay to be switched (0-7).

### 4. Relay

- The number of the relay to be switched in the module selected (1-16). The relay type must be defined as 'Switch' to connect it to the switch. If not the type will be changed to match.

Switches can be either on-screen or on a switchbox. If the switchbox is present it takes priority. Each switch can control one or more sections or zones (defined on the sections page) and one other relay (defined here).