

## **Pressure**

Enter the slope and intercept from the calibration data with the copy button. These values are used to calculate the pressure from the pressure sensor signal. Enter the minimum raw data value below which 0 pressure will be shown.

To enter calibration data set the sprayer at a known pressure. Enter the pressure value and press the add button (+), save the changes. Press the copy button to move the calculated values to the settings. Several entries will improve accuracy.

To delete calibration data select the row and press the delete button, save the changes.

Press show to display the pressure screen.