

If you install the configurations on the controllers manched below, you'll have our ATEM Default config for Mega Panel. 2pcs MK 48 and 1pcs MKT 1 is used together as One ME row. Only by changing the IP address (both for device, and device core options) can they be duplicated for extra ME rows. MKA 4 and MKA 2 is expected to use together as one menu/setting panel.

IP adresse for panels

<i>192.168.10.208</i>	<i>192.168.10.209</i>	<i>192.168.10.210</i>	<i>192.168.10.211</i>
<i>192.168.10.204</i>	<i>192.168.10.205</i>	<i>192.168.10.206</i>	<i>MKA 2</i> <i>192.168.10.207</i>
ME1A - MK 48 192.168.10.200	ME1B - MK 48 192.168.10.201	ME1C - MKT 1 192.168.10.202	MKA 4 192.168.10.203

Panel	Device core	Sends to	Receive From
ME1A - MK 48	BMD Atem	ATEM	ATEM
	Skaarhoj TCP Server	<i>None</i>	ME1B - MK 48
		<i>None</i>	ME1C - MKT 1
	UniSketch Raw Panel	ME1B - MK 48	<i>None</i>
ME1B - MK 48	BMD Atem	ATEM	ATEM
	Skaarhoj TCP Server	<i>None</i>	ME1A - MK 48
		<i>None</i>	ME1C - MKT 1
	UniSketch Raw Panel	ME1A - MK 48	<i>None</i>
ME1C - MKT 1	BMD Atem	ATEM	ATEM
	UniSketch Raw Panel	ME1A - MK 48	<i>None</i>
	UniSketch Raw Panel 2	ME1B - MK 48	<i>None</i>
Menu 1 - MKA 4	BMD Atem	ATEM	ATEM
	Skaarhoj TCP Server	<i>None</i>	Menu 2 - MKA 2
	UniSketch Raw Panel	Menu 2 - MKA 2	<i>None</i>
Menu 2 - MKA 2	BMD Atem	ATEM	ATEM
	Skaarhoj TCP Server	<i>None</i>	Menu 1 - MKA 4
	UniSketch Raw Panel	Menu 1 - MKA 4	<i>None</i>

Panel	Function	USES	Transmission	Note
ME1A+ME1B	MEM E	Which Aux to select source for	Local and send to ME1B/ME1A	
ME1A+ME1B	MEM F	Which DSK KEY to select source for	Local and send to ME1B/ME1A	
ME1A+ME1B	MEM G	Which DSK FILL to select source for	Local and send to ME1B/ME1A	
ME1A+ME1B	MEM H	Which USK KEY+FILL to select source for	Local and send to ME1B/ME1A	
ME1B	Shift 0	0. Shift level, used on HWC A, B and C	Local and send to ME1A	Source 1-22
ME1B	Shift 1	1. Shift level, used on HWC A, B and C	Local and send to ME1A	Source 22+Internal sources
ME1B	Shift 2	2. Shift level, used on HWC A, B and C	Local and send to ME1A	More internal sources
ME1C	MEM A	ME Select	Local and send to ME1A and ME1B	Select what ME is used
ME1C	REG Q	Menu Select	Local and send to 200 and 201	Select what Menu is in Row M at ME1A and ME1B
ME1C	Shift 1	Shift for functions on ME1C	Local	
ME1C	Shift 2	Brings Menu select available	Local	
ME1C	Shift 3	Brings ME select available	Local	
Menu 1	MEM A	ME Select	Local and send to Menu 2	Select what ME is used
Menu 1	MEM E	USK Select	Local and send to Menu 2	