





















## Setup Menu

Adjust basic camera settings.

 See page 271 for details.

 <b>USER SETTING</b>		
 1/2	<b>FORMAT</b>	272
	 <b>AREA SETTING</b>	273
	<b>DATE/TIME</b>	273
	<b>TIME DIFFERENCE</b>	274
	 <b>言語/LANG.</b>	275
	 <b>MY MENU SETTING</b>	275
	 <b>MY MENU SETTING</b>	275
	<b>SENSOR CLEANING</b>	276
	<b>BATTERY AGE</b>	276
	<b>RESET</b>	277
	<b>REGULATORY</b>	277
 <b>SOUND SETTING</b>		
 1/2	<b>AF BEEP VOL.</b>	278
	<b>SELF-TIMER BEEP VOL.</b>	278
	<b>OPERATION VOL.</b>	279
	 <b>REC START/STOP VOLUME</b>	279
	<b>MS EF ELECTRONIC SHUTTER VOLUME</b>	279
	<b>MS EF ELECTRONIC SHUTTER SOUND</b>	280
	<b>ES ELECTRONIC SHUTTER VOLUME</b>	280
	<b>ES ELECTRONIC SHUTTER SOUND</b>	280
	<b>PLAYBACK VOLUME</b>	281
	<b>4ch AUDIO PLAYBACK</b>	281
 <b>SCREEN SETTING</b>		
 1/4	<b>VIEW MODE SETTING</b>	282
	<b>EVF BRIGHTNESS</b>	282
	<b>EVF COLOR</b>	282
	<b>EVF COLOR ADJUSTMENT</b>	283
	<b>LCD BRIGHTNESS</b>	284
	<b>LCD COLOR</b>	284
	<b>LCD COLOR ADJUSTMENT</b>	284
	<b>IMAGE DISP.</b>	285
	<b>AUTOROTATE DISPLAYS</b>	285
	<b>PREVIEW EXP./WB IN MANUAL MODE</b>	286
 2/4	<b>NATURAL LIVE VIEW</b>	286
	<b>F-Log VIEW ASSIST</b>	287
	<b>ELECTRONIC LEVEL SETTING</b>	287
	<b>FRAMING GUIDELINE</b>	288
	<b>AUTOROTATE PB</b>	289
	<b>FOCUS SCALE UNITS</b>	289
	<b>APERTURE UNIT FOR CINEMA LENS</b>	289
	<b>DUAL DISPLAY SETTING</b>	290
	<b>DISP. CUSTOM SETTING</b>	290
	<b>LARGE INDICATORS MODE(EVF)</b>	291
 3/4	<b>LARGE INDICATORS MODE(LCD)</b>	291
	<b>LARGE INDICATORS DISP. SETTING</b>	292
	<b>INFORMATION CONTRAST ADJ.</b>	292
	<b>LOCATION INFO</b>	293
	 <b>Q MENU BACKGROUND</b>	293
	 <b>Q MENU BACKGROUND</b>	293
 4/4		