


AUDIO SETTING (Movie Recording)	214
INTERNAL MIC LEVEL ADJUSTMENT	214
EXTERNAL MIC LEVEL ADJUSTMENT	214
MIC JACK SETTING	214
MIC LEVEL LIMITER	215
WIND FILTER	215
LOW CUT FILTER	215
HEADPHONES VOLUME	215
MIC/REMOTE RELEASE	215
XLR MIC ADAPTER SETTING	216
TIME CODE SETTING (Movie Recording)	217
TIME CODE DISPLAY	217
START TIME SETTING	217
COUNT UP SETTING	217
DROP FRAME	218
HDMI TIME CODE OUTPUT	218

7 Playback and the Playback Menu 219

The Playback Display	220
The DISP/BACK Button	221
Viewing Pictures	223
Playback Zoom	224
Multi-Frame Playback	224
The Playback Menu	225
RAW CONVERSION	225
HEIF TO JPEG/TIFF CONVERSION	228
ERASE	229
CROP	231
RESIZE	232
PROTECT	233
IMAGE ROTATE	234
VOICE MEMO SETTING	235
RATING	236
TRANSFER IMAGE TO SMARTPHONE	237
 WIRELESS COMMUNICATION	239
SLIDE SHOW	239
PHOTOBOOK ASSIST	240