


Shortcut Options

Customize camera controls to suit your style or situation.

Frequently-used options can be added to “my menu” or the Q menu or assigned to the function buttons or touch function button flick gestures for direct access:

Shortcut Option	Description	
“My menu”	Add frequently-used options to this custom menu, which can be viewed by pressing MENU/OK and selecting the MY (“MY MENU”) tab.	245
The Quick Menu	The Q menu is displayed by pressing the Q button. Use the Q menu to view or change the options selected for frequently-used menu items.	247
The function button	Use the function (Fn , Q , and AEL/AFL) button for direct access to selected features.	253
Touch-function gestures	Use touch function button flick gestures (T-Fn1 , T-Fn2 , T-Fn3 , and T-Fn4) for direct access to selected features.	256