

## Shooting

Shoot photos and record movies while viewing the scene through the camera lens or saving footage to the HDMI device.



This feature can be used to save 4K and Full HD movies to an HDMI recorder.

## Playback

To start playback, press the camera **PLAY** button. The camera monitor turns off and pictures and movies are output to the HDMI device. Note that the camera volume controls have no effect on sounds played on the TV; use the television volume controls to adjust the volume.



- Some televisions may briefly display a black screen when movie playback begins.
- An adapter cable (sold separately; 321) is required when using headphones.