

7 Playback and the Playback Menu 213

The Playback Display	214
The DISP/BACK Button.....	216
Viewing Pictures	218
Playback Zoom	219
Multi-Frame Playback.....	219
The Playback Menu	220
SWITCH SLOT	220
RAW CONVERSION	221
HEIF TO JPEG/TIFF CONVERSION	223
ERASE.....	224
SIMULTANEOUS DELETE.....	226
CROP	226
RESIZE.....	227
PROTECT.....	228
IMAGE ROTATE	229
VOICE MEMO SETTING.....	230
RATING	231
COPY	232
TRANSFER IMAGE TO SMARTPHONE.....	233
📷📶 WIRELESS COMMUNICATION.....	235
DESQUEEZE DISP. IN PLAYBACK	235
PHOTOBOOK ASSIST	236
PRINT ORDER (DPOF)	238
instax PRINTER PRINT	239
DISP ASPECT	240

8 Network/USB Setting Menus 241

Overview	242
Supported Features	242
Connection Setting Profiles.....	246