




CH HIGH SPEED BURST

Select the frame rate used when the drive dial is rotated to **CH** (continuous high speed). The display frame rate when the electronic shutter is used is 40 fps, or 60 fps in 1.29× crop mode.

Options		
20fps(1.29X CROP)  ¹	13fps(1.29X CROP)  ¹	10fps(1.29X CROP)  ¹
15fps ²	10fps ³	

¹ Available with electronic shutter only.

² 13 fps with electronic shutter.

³ 8.9 fps with electronic shutter.


CL LOW SPEED BURST

Select the frame rate used when the drive dial is rotated to **CL** (continuous low speed).

Options		
7.0fps*	5.0fps	3.0fps

* 6.7 fps with electronic shutter.

HDR MODE

Each time the shutter button is pressed, the camera takes three shots, varying exposure each time, and combines them into a single picture. The resulting photograph preserves details in highlights and shadows ( 107).

ADV. FILTER SETTING

Choose the filter used when the drive dial is rotated to **ADV.** ( 110).