
































Movie Menus

  Items marked with both  and  icons are available in both the still photography and movie shooting menus. Changes to these items in either menu also apply to the item in the remaining menu.

 MOVIE SETTING		 IMAGE QUALITY SETTING	
MOVIE SETTING LIST	187	 FILM SIMULATION	201
MOVIE MODE	188	 MONOCHROMATIC COLOR	201
HIGH SPEED REC	189	 WHITE BALANCE	202
 SELF-TIMER	190	 DYNAMIC RANGE	202
$\frac{1}{3}$ MEDIA REC SETTING	190	$\frac{1}{2}$  TONE CURVE	202
HDMI OUTPUT SETTING	192	 COLOR	202
FIX MOVIE CROP MAGNIFICATION	193	 SHARPNESS	203
F-Log/HLG RECORDING	194	 HIGH ISO NR	203
DATA LEVEL SETTING	195	INTERFRAME NR	203
 PHOTOMETRY	195	$\frac{2}{3}$  PERIPHERAL LIGHT CORRECTION	204
 FLICKERLESS S.S. SETTING	195	  MOUNT ADAPTOR SETTING	204
$\frac{2}{3}$  IS MODE	196		
 IS MODE BOOST	196		
ZEBRA SETTING	197		
ZEBRA LEVEL	197		
MOVIE OPTIMIZED CONTROL 	198		
 REC FRAME INDICATOR	198		
TALLY LIGHT	199		
$\frac{3}{4}$  SELECT CUSTOM SETTING	200		
 EDIT/SAVE CUSTOM SETTING	200		
 AUTO UPDATE CUSTOM SETTING	200		
  WIRELESS COMMUNICATION	200		