

- 9 Name the communication setting profile.
- 10 When prompted, press **MENU/OK** and adjust settings for connection to the FTP server (📖 285).
- 11 Save the connection setting profile when adjustments to settings are complete.
Press **MENU/OK**.
- 12 Select **CREATE NEW**.
- 13 Name the connection setting profile.

