



































Movie Menus

  Items marked with both  and  icons are available in both the still photography and movie shooting menus. Changes to these items in either menu also apply to the item in the remaining menu.

 MOVIE SETTING		 IMAGE QUALITY SETTING	
MOVIE SETTING LIST	177	 FILM SIMULATION	194
IMAGE FORMAT	177	 MONOCHROMATIC COLOR	194
MOVIE MODE	178	 DYNAMIC RANGE	195
1/4 HIGH SPEED REC	179	 WHITE BALANCE	195
 SELF-TIMER	180	 TONE CURVE	195
MEDIA REC SETTING	181	 COLOR	195
HDMI OUTPUT SETTING	184	 SHARPNESS	196
FIX MOVIE CROP MAGNIFICATION	185	 HIGH ISO NR	196
F-Log/HLG RECORDING	186	INTERFRAME NR	196
DATA LEVEL SETTING	187	  PIXEL MAPPING	196
 PHOTOMETRY	187	2 1/2 F-Log2 D RANGE PRIORITY	197
 FLICKERLESS S.S. SETTING	187	 PERIPHERAL LIGHT CORRECTION	197
2 1/4 IS MODE	188	  MOUNT ADAPTOR SETTING	197
 IS MODE BOOST	188		
 ISO	189		
ZEBRA SETTING	189		
ZEBRA LEVEL	189		
WAVEFORM/VECTORSCOPE	190		
MOVIE OPTIMIZED CONTROL 	191		
 REC FRAME INDICATOR	191		
3 1/4 TALLY LIGHT	192		
  COOLING FAN SETTING	193		
 EDIT/SAVE CUSTOM SETTING	193		
 AUTO UPDATE CUSTOM SETTING	193		
4 1/4   WIRELESS COMMUNICATION	193		