
















TTL-LOCK MODE .....	181
LED LIGHT SETTING .....	181
COMMANDER SETTING .....	182
CH SETTING .....	182
<b>MOVIE SETTING (Still Photography) .....</b>	<b>183</b>
MOVIE MODE .....	183
HIGH SPEED REC .....	183
MEDIA REC SETTING .....	183
 IS MODE .....	184
 IS MODE BOOST .....	184
AUDIO SETTING .....	184
 REC FRAME INDICATOR .....	186
<b>MOVIE SETTING (Movie Recording) .....</b>	<b>187</b>
MOVIE SETTING LIST .....	187
MOVIE MODE .....	188
HIGH SPEED REC .....	189
 SELF-TIMER .....	190
MEDIA REC SETTING .....	190
HDMI OUTPUT SETTING .....	192
FIX MOVIE CROP MAGNIFICATION .....	193
F-Log/HLG RECORDING .....	194
DATA LEVEL SETTING .....	195
 PHOTOMETRY .....	195
 FLICKERLESS S.S. SETTING .....	195
 IS MODE .....	196
 IS MODE BOOST .....	196
ZEBRA SETTING .....	197
ZEBRA LEVEL .....	197
MOVIE OPTIMIZED CONTROL  .....	198
 REC FRAME INDICATOR .....	198
TALLY LIGHT .....	199
 SELECT CUSTOM SETTING .....	200
 EDIT/SAVE CUSTOM SETTING .....	200
 AUTO UPDATE CUSTOM SETTING .....	200
  WIRELESS COMMUNICATION .....	200