








Using the Fan

Fan speed can be adjusted using the  **SHOOTING SETTING** >   **COOLING FAN SETTING** and  **MOVIE SETTING** >   **COOLING FAN SETTING** options in the photo and movie menus, respectively. Select **OFF** to turn the fan off.

-  At some speeds, the noise of the fan may be audible in movies recorded with the camera.
- Depending on the LCD orientation, the EVF turns off, and the LCD only turns on.