



- **AUTO:** In **AUTO** mode, the camera calculates **FRAMES** and **STEP** automatically.

1 Navigate to **SHOOTING SETTING > DRIVE SETTING > BKT SETTING** in the photo menus, highlight **FOCUS BKT**, and press **MENU/OK**.


2 Select **AUTO** and choose an **INTERVAL**.
The view through the lens will be displayed.

3 Focus on the nearest end of the subject and press **MENU/OK**.
The selected focus distance appears as **A** on the focus distance indicator.



 The same focus range can be chosen by focusing on the farthest end of the subject first.

4 Focus on the farthest end of the subject and press **DISP/BACK**.
The selected focus distance (**B**) and focus range (**A to B**) appear on the focus distance indicator.



 Instead of pressing the **DISP/BACK** button, you can press **MENU/OK** and select **A** again.

5 Take photographs.
The camera will calculate values for **FRAMES** and **STEP** automatically.
The number of frames will appear in the display.

