

① Sports finder mode.....	138	②⑧ External power source in use.....	37
② Focus check .....	76, 131	②⑨ Battery level.....	39
③ ND (Neutral Density) filter indicator .....	150	③⑩ Sensitivity.....	77
④ Depth-of-field preview.....	62, 75	③⑪ Exposure compensation.....	81
⑤ Conversion lens .....	150	③⑫ Aperture.....	57, 62, 63
⑥ Digital teleconverter .....	150	③⑬ Time code.....	169
⑦ Bluetooth ON/OFF.....	236	③⑭ Shutter speed .....	57, 58, 63
⑧ Image transfer status .....	236, 274	③⑮ TTL lock.....	153, 223, 254
⑨ Movie mode <sup>3</sup> .....	50, 155	③⑯ AE lock.....	84, 228
⑩ Time remaining <sup>3</sup> .....	51	③⑰ Metering.....	79
⑪ Date and time.....	40, 42, 201	③⑱ Shooting mode .....	56
⑫ Number of available frames <sup>1</sup> .....	317	③⑲ Focus mode <sup>2</sup> .....	66
⑬ Image size.....	104	④① Focus indicator <sup>2</sup> .....	67
⑭ Image quality.....	105	④② Manual focus indicator <sup>2</sup> .....	66, 73
⑮ Temperature warning .....	316	④③ AF lock.....	84, 228
⑯ Touch screen mode <sup>4</sup> .....	24, 134	④④ Distance indicator <sup>2</sup> .....	75
⑰ White balance .....	110	④⑤ Recording level <sup>2,3</sup> .....	167
⑱ AWB lock .....	228	④⑥ AF+MF indicator <sup>2</sup> .....	130
⑲ Film simulation .....	106	④⑦ Shutter type .....	147
⑳ Dynamic range .....	113	④⑧ Continuous mode.....	89
㉑ D-range priority .....	114	④⑨ Exposure indicator.....	63, 81
㉒ Control lock <sup>5</sup> .....	230	④⑩ Self-timer indicator .....	139
㉓ Sound and flash indicator .....	203	⑤① Flash (TTL) mode.....	263
㉔ Boost mode .....	231	⑤② Microphone.....	168
㉕ Virtual horizon.....	22	⑤③ Remote release.....	168
㉖ Histogram.....	22	⑤④ Flash compensation.....	263
㉗ Focus frame.....	70, 83	⑤⑤ Location data download status.....	241, 274

1 Shows "9999" if there is space for over 9999 frames.

2 Not displayed in the EVF if **LARGE INDICATORS MODE(EVF/OVF)** is selected for **SCREEN SET-UP** or in the LCD monitor if **LARGE INDICATORS MODE(LCD)** is selected.

3 Displayed during movie recording only.

4 Displayed in the LCD monitor only. Camera functions can also be accessed via touch controls.

5 Displayed when controls have been locked by pressing and holding the **MENU/OK** button. Control lock can be ended by pressing and holding the **MENU/OK** button again.