







TOUCH SCREEN MODE

Choose the shooting operations performed using touch controls.

Still Photography

| Mode | Description |
|--|---|
|  TOUCH SHOOTING | Tap your subject in the display to focus and release the shutter. In burst mode, pictures will be taken while you keep your finger on the display. |
|  AF   AF OFF | <ul style="list-style-type: none">• In focus mode S (AF-S), the camera focuses when you tap your subject in the display. Focus locks at the current distance until you tap the AF OFF icon.• In focus mode C (AF-C), the camera initiates focus when you tap your subject display. The camera will continue to adjust focus for changes in the distance to the subject until you tap the AF OFF icon.• In manual focus mode (MF), you can tap the display to focus on the selected subject using autofocus. |
|  AREA | Tap to select a point for focus or zoom. The focus frame will move to the selected point. |
|  OFF | Touch controls disabled. |