














Setup Menus

Adjust basic camera settings.

 See page 269 for details.

 USER SETTING		 SCREEN SETTING	
FORMAT	270	VIEW MODE SETTING	278
 AREA SETTING	271	EVF BRIGHTNESS	278
DATE/TIME	271	EVF COLOR	278
TIME DIFFERENCE	272	EVF COLOR ADJUSTMENT	279
 言語/LANG.	272	LCD BRIGHTNESS	279
 MY MENU SETTING	273	LCD COLOR	279
 MY MENU SETTING	273	LCD COLOR ADJUSTMENT	279
SENSOR CLEANING	273	IMAGE DISP.	280
BATTERY AGE	273	AUTOROTATE DISPLAYS	280
SOUND & FLASH	274	PREVIEW EXP./WB IN MANUAL MODE	281
RESET	274	NATURAL LIVE VIEW	281
REGULATORY	274	F-Log VIEW ASSIST	282
SOUND SETTING		ELECTRONIC LEVEL SETTING	282
AF BEEP VOL.	275	FRAMING GUIDELINE	282
SELF-TIMER BEEP VOL.	275	AUTOROTATE PB	283
OPERATION VOL.	275	FOCUS SCALE UNITS	283
 REC START/STOP VOLUME	276	APERTURE UNIT FOR CINEMA LENS	283
MS ELECTRONIC SHUTTER VOLUME	276	DISP. CUSTOM SETTING	283
MS ELECTRONIC SHUTTER SOUND	276	LARGE INDICATORS MODE(EVF)	284
ES ELECTRONIC SHUTTER VOLUME	277	LARGE INDICATORS MODE(LCD)	285
ES ELECTRONIC SHUTTER SOUND	277	LARGE INDICATORS DISP. SETTING	286
PLAYBACK VOLUME	277	INFORMATION CONTRAST ADJ.	287
4ch AUDIO PLAYBACK	277	LOCATION INFO	287
		 Q MENU BACKGROUND	288
		 Q MENU BACKGROUND	288