



## MF ASSIST


Choose how focus is displayed in manual focus mode ( 94).


Option	Description
<b>FOCUS PEAK HIGHLIGHT</b>	The camera heightens high-contrast outlines. Choose a color and peaking level.
<b>FOCUS METER</b>	A needle indicates whether focus is in front of or behind the subject.
<b>FOCUS METER + PEAK HIGHLIGHT</b>	Focus is indicated by both a meter and peak highlights.
<b>OFF</b>	Focus is displayed normally (focus peaking and the focus meter are not available).

## FOCUS CHECK

Options are the same as those for still photography, but settings must be adjusted separately ( 156).

## INSTANT AF SETTING

This item is also found in the photo menus ( 157). Changes to one apply to the other.

 Instant AF is disabled during movie recording. Use instant AF to focus before recording begins.