



The Playback Menu

Adjust playback settings.

 See page 225 for details.

PLAY BACK MENU			PLAY BACK MENU		
1/3	SWITCH SLOT	225	2/3	IMAGE ROTATE	235
	RAW CONVERSION	226		VOICE MEMO SETTING	236
	HEIF TO JPEG/TIFF CONVERSION	229		RATING	237
	ERASE	230		COPY	238
	SIMULTANEOUS DELETE	232		TRANSFER IMAGE TO SMARTPHONE	239
	CROP	232		 WIRELESS COMMUNICATION	241
	RESIZE	233		SLIDE SHOW	241
PROTECT	234		PHOTOBOOK ASSIST	242	
			PRINT ORDER (DPOF)	244	
			3/3 instax PRINTER PRINT	245	
			DISP ASPECT	246	