













## 4K MOVIE OUTPUT





Choose the destination for 4K movies shot while the camera is connected to an HDMI recorder or other device that supports 4K.

Option	Description
 <b>4K</b>  <b>4K</b>	4K movies are recorded to the camera memory card and output to the HDMI device in 4K.
 <b>4K</b>  <b>FHD</b>	4K movies are recorded to a camera memory card in 4K and output to the HDMI device in Full HD.
 <b>FHD</b>  <b>4K</b>	4K movies are output to the HDMI device in 4K and recorded to the camera memory card in Full HD.
 <b>—</b>  <b>4K</b>	4K movies are output to the HDMI device in 4K. The camera does not record 4K movies to a memory card.

 This option is only available when  **16:9** or  **17:9** is selected for  **MOVIE SETTING > MOVIE MODE** in the shooting menu.

## FULL HD MOVIE OUTPUT

Choose the destination for Full HD movies shot while the camera is connected to an HDMI device.

Option	Description
 <b>FHD</b>  <b>FHD</b>	Full HD movies are output to the HDMI device and recorded to the camera memory card.
 <b>—</b>  <b>FHD</b>	Full HD movies are not recorded to the camera memory card but are output to the HDMI device.

 • This option is only available when  **16:9** or  **17:9** is selected for  **MOVIE SETTING > MOVIE MODE** in the shooting menu.

• When **OFF** is selected for **HDMI OUTPUT INFO DISPLAY**, movies will be output to the HDMI device in 4:2:2 10-bit format.