

LOCATION INFO

Select **ON** to display location info downloaded from a smartphone.

| Options | |
|-----------|------------|
| ON | OFF |

SUB MONITOR SETTING

Choose the indicators displayed in the secondary LCD monitor. Separate displays are available for still photography and movie recording. Choose from the following:

| Option | Description |
|--------------------|---|
| INFORMATION | Display camera settings. You can choose the settings displayed. |
| DIALS | Display dials showing ISO sensitivity and shutter speed. |
| HISTOGRAM | Display a histogram. |



You can switch between displays by pressing the secondary LCD monitor mode button.

The INFORMATION Display

Follow the steps below to choose the indicators shown in the INFORMATION display.

- 1 Select **SCREEN SET-UP > SUB MONITOR SETTING** in the setup menu.
- 2 Highlight **STILL MODE** or **MOVIE MODE** and press **MENU/OK**.
- 3 Highlight **INFORMATION** and press **MENU/OK**.

