

Miscellaneous

Problem	Solution
The camera is unresponsive.	<ul style="list-style-type: none"> • Temporary camera malfunction: Remove and reinsert the battery (📖 43). • The battery is exhausted: Charge the battery or insert a fully-charged spare battery (📖 50). • The camera is connected to a wireless LAN: End the connection. • The controls are locked: Press and hold the MENU/OK button to unlock the controls (📖 17, 19).
The camera does not function as expected.	Remove and reinsert the battery (📖 43). If the problem persists, contact your Fujifilm dealer.
No sound.	Adjust the volume (📖 338).
Pressing the Q button does not display the quick menu.	TTL-LOCK is active: End TTL-LOCK (📖 175).