



- Press **MENU/OK** to pause playback and display volume controls. Press the focus stick (focus lever) up or down to adjust the volume; press **MENU/OK** again to resume playback. Volume can also be adjusted using **▣ SOUND SET-UP > PLAYBACK VOLUME**.
- To view movies on a television connected via HDMI instead of in the camera monitor, press the **▣** button.

### Playback Speed

Press the focus stick (focus lever) left or right to adjust playback speed during playback. Speed is shown by the number of arrows (▶ or ◀).



Arrows

## Viewing Movies During Vlog Recording

When the mode dial is rotated to **Vlog**, you can view your most recent shot by pressing the **Vlog** button and then tapping **▣** in the display.



- Tap the display to begin playback.
- Tap **◀** or **▶** to select other shots.
- To delete the current shot, tap **▣**.



If you have viewed other items since your last shot, the most-recently viewed item will be displayed.