


| Warning   | Description   |
|---|---|
| <b>CARD ERROR</b>   | <ul style="list-style-type: none"> <li>• <b>The memory card is not formatted for use in the camera:</b> Format the card.</li> <li>• <b>The memory card contacts require cleaning or the memory card is damaged:</b> Clean the contacts with a soft, dry cloth. If the message is repeated, format the card. If the message persists, replace the card.</li> <li>• <b>Incompatible memory card:</b> Use a compatible card.</li> <li>• <b>Camera malfunction:</b> Contact a Fujifilm dealer.</li> </ul> |
| <b>PROTECTED CARD</b>   | The memory card is locked. Unlock the card.   |
| <b>BUSY</b>   | The memory card is incorrectly formatted. Use the camera to format the card.  |
|  <b>MEMORY FULL</b> | The memory card is full and pictures cannot be recorded. Delete pictures or insert a memory card with more free space.  |