



- | | |
|--|---|
| ①⑨ Diopter adjustment control..... 9 | ②⑧ DISP (display)/ BACK button..... 16, 183 |
| ②① Electronic viewfinder (EVF)
..... 10, 14, 16, 21 | ②⑨ Cable channel cover for DC coupler..... 298 |
| ②② DRIVE/DELETE button..... 5, 46, 87 | ③① Battery-chamber cover..... 30 |
| ②③ PLAY (playback) button..... 45 | ③② Tripod mount |
| ②④ AEL (exposure lock)/ AFL (focus lock) button
..... 86, 253 | ③③ Speaker..... 52, 214 |
| ②⑤ Indicator lamp..... 7, 163 | ③④ LCD monitor..... 8, 12, 14 |
| Tally light..... 163 | Touch screen..... 21, 138, 230 |
| ②⑥ Focus stick (focus lever)..... 5, 74, 224 | ③⑤ Battery chamber..... 30 |
| ②⑦ MENU/OK button..... 19 | ③⑥ Memory card slot..... 30 |
| | ③⑦ Battery latch..... 31 |
| | ③⑧ Serial number plate..... see below |

- ❗ ①⑥ Use of an optional RR-100 remote release requires a third-party adapter to convert the female three-pin, $\varnothing 2.5$ mm connector to a male three-pin, $\varnothing 3.5$ mm connector.
- ③⑧ Do not remove the serial number plate, which provides the CMIIT ID, serial number, and other important information.