

Item	Description
① Camera settings	Adjust settings for the current camera.
② Choose for REC/STOP	Choose the camera or cameras to which the selected action (starting or stopping recording) will apply.
③ STOP button	Stop movie recording.
④ REC button	Start movie recording.
⑤ Choose camera	A list of thumbnails showing the views through the lenses of the connected cameras. Click or tap a thumbnail to select a camera to control.
⑥ Check button for movies in memory card	View the movies on the memory card in the current camera.
⑦ Camera settings (advanced)	Adjust (advanced) settings for the current camera.
⑧ Screen lock button	Enable or disable the controls in the remote recording display.
⑨ Display mode button	Switch displays.
⑩ Remote recording menu	Adjust remote recording settings (📖 309).
⑪ Camera lock button	Lock or unlock the current camera, enabling or disabling its controls.



If you end the connection to a camera while it is locked, its controls will remain disabled, in which case you will need to turn the camera off.