

Problem	Solution
<b>Charging does not start (USB).</b>	<ul style="list-style-type: none"> <li>• Insert the camera battery (📖 32).</li> <li>• Reinsert the camera battery in the correct orientation (📖 32).</li> <li>• Confirm that the camera is connected to the computer (📖 36).</li> <li>• If the computer is off or in sleep mode, turn on or wake the computer and disconnect and reconnect the USB cable (📖 36).</li> </ul>
<b>Charging does not start (battery charger).</b>	<ul style="list-style-type: none"> <li>• Insert the battery.</li> <li>• Reinsert the battery in the correct orientation.</li> <li>• Make sure that the charger is correctly plugged in.</li> <li>• Ensure that the plug adapter is correctly connected to the charger.</li> </ul>
<b>Charging is slow.</b>	Charge the battery at room temperature.
<b>The indicator lamp blinks, but the battery does not charge.</b>	<ul style="list-style-type: none"> <li>• <b>There is dirt on the battery terminals:</b> Clean the terminals with a soft, dry cloth (📖 32).</li> <li>• <b>The battery has been charged many times:</b> The battery has reached the end of its charging life. Purchase a new battery. If the battery still fails to charge, contact your Fujifilm dealer (📖 288).</li> </ul>
<b>The external power source icon is not displayed.</b>	Confirm that <b>ON</b> is selected for <b>USB POWER SUPPLY SETTING</b> (📖 240).

## Menus and Displays

Problem	Solution
<b>Display is not in English.</b>	Select <b>ENGLISH</b> for <b>🔧 USER SETTING &gt; 🗣️ 言語/LANG.</b> (📖 42, 202).