


- ❗ If the correct exposure cannot be achieved at the selected aperture, shutter speed will be displayed in red.
- If the subject is outside the metering range of the camera, the shutter speed display will show “— —”.
- To use the shutter speed dial, press the dial lock release and rotate the dial to the desired setting.
- If the lens is not equipped with an aperture ring, select **MANUAL** for **⚙️ BUTTON/DIAL SETTING > APERTURE SETTING**.

📷 Aperture can be adjusted even while the shutter button is pressed halfway.

Previewing Depth of Field

When **PREVIEW DEPTH OF FIELD** is assigned to a function button, pressing the button displays a  icon and stops aperture down to the selected setting, allowing depth of field to be previewed in the display.

