

Supplied Accessories

The following are included with the camera:

- NP-W235 rechargeable battery



For reasons of safety, the battery is not charged at shipment. The camera will not function if the battery is not charged; be sure to charge the battery before use (📖 42).

- AC-5VJ AC power adapter
- Plug adapter
- USB cable (approx. 0.6 m/2 ft.)
- Body cap (comes attached to camera)
- Shoulder strap
- Hot shoe cover (comes attached to hot shoe)
- Sync terminal cap (comes attached to camera)
- Headphone adapter
- *Basic Manual*



- If you purchased a lens kit, check that a lens is included.
- The plug adapter supplied varies with the country or region.
- The headphone adapter converts the USB Type-C connector to a ø3.5 mm headphone jack.
- For information on compatible computer software, see “Software for Use with Your Camera” (📖 359).