


## MOVIE OPTIMIZED CONTROL


Select **ON** to allow movie settings to be adjusted using only the command dials and touch-screen controls. You may find this helpful in preventing the sounds of camera controls being recorded with movies ( 28).

| Options |     |
|---------|-----|
| ON      | OFF |

## REC FRAME INDICATOR

If **ON** is selected, the borders of the display will turn red during movie recording.

| Options |     |
|---------|-----|
| ON      | OFF |

 The borders are displayed in green during high-speed movie recording.