

① Crop factor.....	194	③② Boost mode.....	302
② Location data download status.....	247, 305	③③ Touch zoom ³	29
③ Focus check.....	102, 161	③④ Temperature warning.....	35, 386
④ Depth-of-field preview.....	76, 101	③⑤ Control lock ⁴	300
⑤ Movie compression.....	191	③⑥ Battery level.....	42
⑥ Image transfer status.....	247, 262	③⑦ Power supply.....	39
⑦ Bluetooth ON/OFF.....		③⑧ Sensitivity.....	104
⑧ Bluetooth host.....	247	③⑨ Histogram.....	20
⑨ Movie mode.....	56, 187	④① Exposure compensation.....	107
⑩ High-speed recording indicator.....	189	④② Distance indicator ²	101
⑪ Focus frame.....	96, 108	④③ Aperture.....	71, 75, 77
⑫ Recording time available/ elapsed recording time.....	56	④④ Time code.....	217
⑬ Date and time.....	43, 45, 271	④⑤ Shutter speed.....	71, 73, 77
⑭ Destination for movie recording.....	190	④⑥ TTL lock.....	179, 320
⑮ Number of available frames ¹	387	④⑦ AE lock.....	109, 296
⑯ Background defocus mode.....	188	④⑧ Metering.....	106
⑰ Image size.....	128	④⑨ Shooting mode.....	68
⑱ File format.....	191	④⑩ Custom modes.....	82
⑲ Image quality.....	129	⑤① Focus mode ²	92
⑳ Product priority mode.....	208	⑤② Focus indicator ²	93
㉑ HEIF format.....	131	⑤③ Manual focus indicator ²	92, 100
㉒ Cooling fan settings.....	177, 347	⑤④ AF lock.....	109, 296
㉓ Touch screen mode ³	25, 165	⑤⑤ Microphone input channel.....	184, 216
㉔ AWB lock.....	296	⑤⑥ AF+MF indicator ²	160
㉕ White balance.....	136	⑤⑦ Shutter type.....	172
㉖ Film simulation.....	132	⑤⑧ Recording level ²	214
㉗ F-Log/HLG recording.....	195	⑤⑨ Continuous mode.....	115
㉘ Dynamic range.....	140	⑤⑩ Self-timer indicator.....	169, 190
㉙ D-range priority.....	140	⑥① Exposure indicator.....	77, 107
㉚ Movie optimized control ³	27	⑥② Flash (TTL) mode.....	340
㉛ Virtual horizon.....	21	⑥③ Flash compensation.....	340
		⑥④ IS mode ²	176

1 Shows "9999" if there is space for over 9999 frames.

2 Not displayed when **ON** is selected for **SCREEN SET-UP > LARGE INDICATORS MODE(LCD)**.

3 Camera functions can also be accessed via touch controls.

4 Displayed when controls have been locked by pressing and holding the **MENU/OK** button. Control lock can be ended by pressing and holding the **MENU/OK** button again.