



29	🗑️ (delete) button	59	42	Selector buttons	4
30	▶️ (playback) button	56	43	MENU/OK button	24
31	Electronic viewfinder (EVF)	12, 16, 18, 26	44	Battery-chamber cover latch	36
32	Eye cup (lockable)	11	45	Battery-chamber cover	36
33	VIEW MODE button	16	46	DISP (display)/BACK button	19, 221
34	AFON button	102, 321	Ⓜ️ (Bluetooth) button	249	
35	Rear command dial	7, 223, 296	47	Tripod mount	
36	Q (quick menu) button	315	48	LCD monitor	10, 14, 16
37	Indicator lamp	9, 199		Touch screen	26, 160, 210
	Tally light	199	49	Eye sensor	16
38	AEL (exposure lock) button	102, 321	50	Memory card slot 2	38
39	Focus stick (focus lever)	4, 87, 294	51	Memory card slot 1	38
40	Memory card slot cover latch	38	52	Battery chamber	36
41	Memory card slot cover	38	53	Battery latch	37
			54	Serial number plate	4