






| Problem                        | Solution  |
|--------------------------------|---|
| The battery runs down quickly. | <ul style="list-style-type: none"> <li>• <b>The battery is cold:</b> Warm the battery by placing it in a pocket or other warm place and reinsert it in the camera immediately before taking a picture.</li> <li>• <b>There is dirt on the battery terminals:</b> Clean the terminals with a soft, dry cloth.</li> <li>• <b>ON is selected for  AF/MF SETTING &gt; PRE-AF:</b> Turn <b>PRE-AF</b> off ( 149).</li> <li>• <b>The battery has been charged many times:</b> Select <b>BATTERY AGE</b> to view the battery age; if the battery is old, replace it with a new battery ( 276).</li> </ul> |
| The camera turns off suddenly. | <b>The battery is exhausted:</b> Charge the battery or insert a fully-charged spare battery (  42).  |
| The camera does not turn off.  | The camera may be busy. Check the indicator lamp (  9).  |