
















TTL-LOCK MODE	181
LED LIGHT SETTING	181
COMMANDER SETTING	182
CH SETTING	182
MOVIE SETTING (Still Photography)	183
MOVIE MODE	183
HIGH SPEED REC	183
MEDIA REC SETTING	183
 IS MODE	184
 IS MODE BOOST	184
AUDIO SETTING	184
 REC FRAME INDICATOR	186
MOVIE SETTING (Movie Recording)	187
MOVIE SETTING LIST	187
MOVIE MODE	188
HIGH SPEED REC	189
 SELF-TIMER	190
MEDIA REC SETTING	190
HDMI OUTPUT SETTING	192
FIX MOVIE CROP MAGNIFICATION	193
F-Log/HLG RECORDING	194
DATA LEVEL SETTING	195
 PHOTOMETRY	195
 FLICKERLESS S.S. SETTING	195
 IS MODE	196
 IS MODE BOOST	196
ZEBRA SETTING	197
ZEBRA LEVEL	197
MOVIE OPTIMIZED CONTROL 	198
 REC FRAME INDICATOR	198
TALLY LIGHT	199
 SELECT CUSTOM SETTING	200
 EDIT/SAVE CUSTOM SETTING	200
 AUTO UPDATE CUSTOM SETTING	200
  WIRELESS COMMUNICATION	200