

## VECTORSCOPE


A vectorscope is displayed.



## OFF

Neither a waveform monitor, a parade, nor a vectorscope is displayed.

## MOVIE OPTIMIZED CONTROL


Select **ON** to allow movie settings to be adjusted using only the command dials and touch-screen controls. You may find this helpful in preventing the sounds of camera controls being recorded with movies ( 36).

Options	
ON	OFF

## REC FRAME INDICATOR

If **ON** is selected, the borders of the display will turn red during movie recording.

Options	
ON	OFF

 The borders are displayed in green during high-speed movie recording.