



#### 4 Rotate the shutter speed dial to choose a shutter speed and the lens aperture ring to choose an aperture.

 The manual exposure display includes an exposure indicator that shows the amount the picture would be under- or over-exposed at current settings.


 To use the shutter speed dial, press the dial lock release and rotate the dial to the desired setting.

 Shutter speed can be adjusted in increments of  $\frac{1}{3}$  EV by rotating the rear command dial.

#### Exposure Preview

To preview exposure in the LCD monitor, select **PREVIEW EXP./WB** for **SCREEN SET-UP > PREVIEW EXP./WB IN MANUAL MODE**.



 Select an option other than **PREVIEW EXP./WB** when using the flash or on other occasions on which exposure may change when the picture is taken.