

- 3 Press the focus stick (focus lever) up or down to highlight a frame rate ((2)) and press the stick right.

Options					
23.98P	24P	25P	29.97P	50P	59.94P

- 4 Press the focus stick up or down to highlight a bit rate ((3)) and press **MENU/OK**.

Options		
50Mbps	100Mbps	200Mbps



The choice of frame and bit rates varies with the movie mode.

FULL HD HIGH SPEED REC

Record high-frame-rate Full HD movies. High-frame-rate movies can be played back in slow motion, giving you time to view fast-moving subjects or details too fleeting for the naked eye.

Option	Description
2x [▶] 59.94P [📺] 120P	Record Full HD footage at frame rates of 120 or 100 fps. The movies play back at ½, ¼, or ⅓ speed. Maximum recording length is 6 minutes. The footage recorded to the memory card is compressed with the goal of keeping the amount of data recorded to 200 Mbps per second.
2x [▶] 50P [📺] 100P	
4x [▶] 29.97P [📺] 120P	
4x [▶] 25P [📺] 100P	
5x [▶] 24P [📺] 120P	
5x [▶] 23.98P [📺] 120P	High-speed recording off.
OFF	



High-speed movies are recorded with no sound.