

10	Peripherals and Optional Accessories	259
	Lenses	260
	Lens Parts	260
	Removing Lens Caps	261
	Attaching Lens Hoods	261
	Lenses with Aperture Rings	262
	Lenses with No Aperture Rings	263
	Lenses with O.I.S. Switches	263
	Manual Focus Lenses	264
	Lens Care	265
	External Flash Units	266
	Using an External Flash	267
	EF-X8	268
	SYNC TERMINAL	270
	SHOE MOUNT FLASH	271
	COMMANDER(OPTICAL)	274
	Handgrips	278
	Thumb Rests	279
11	Connections	281
	HDMI Output	282
	Connecting to HDMI Devices	282
	Shooting	283
	Playback	283
	Wireless Connections (Bluetooth®, Wireless LAN/Wi-Fi)	284
	Smartphones and Tablets: FUJIFILM Camera Remote	284
	Copying Pictures to a Computer: PC AutoSave	286
	Connecting via USB	287
	Connecting to Computers	287
	Copying Pictures to a Computer	290
	Using Your Camera as a Webcam (FUJIFILM X Webcam)	290
	Converting RAW Images: FUJIFILM X RAW STUDIO	291
	Backing up and Restoring Camera Settings (FUJIFILM X Acquire)	291
	Connecting to Smartphones	292