

Supplied Accessories

The following are included with the camera:

- NP-W126S rechargeable battery
- USB cable
- Lens cap (comes attached to camera)
- Metal strap clips (× 2)
- Clip attaching tool
- Protective covers (× 2)
- Shoulder strap
- Hot shoe cover (comes attached to hot shoe)
- *Owner's Manual* (this manual)



For information on compatible computer software, see “Software for Use with Your Camera” (📖 291).