

Supplied Accessories

The following are included with the camera:

- NP-W126S rechargeable battery
- Body cap (comes attached to camera)
- USB cable
- Headphone adapter
- Shoulder strap
- *Basic Manual*



The battery is not charged at shipment. Charge the battery before use (📖 33).



- If you purchased a lens kit, check that a lens is included.
- Purchasers of the accessory kit should confirm that it includes a hand grip and thumb rest.
- The supplied headphone adapter converts USB Type-C connectors to ø3.5 mm headphone jacks.
- For information on compatible computer software, see “Software for Use with Your Camera” (📖 301).