











FLASH SETTING (Still Photography)	178
FLASH FUNCTION SETTING	178
RED EYE REMOVAL	178
TTL-LOCK MODE	179
LED LIGHT SETTING	179
COMMANDER SETTING	180
CH SETTING	180
MOVIE SETTING (Still Photography)	181
MOVIE MODE	181
HIGH SPEED REC	181
MEDIA REC SETTING	181
 IS MODE	182
 IS MODE BOOST	182
AUDIO SETTING	182
MIC/REMOTE RELEASE	185
 REC FRAME INDICATOR	185
MOVIE SETTING (Movie Recording)	186
MOVIE SETTING LIST	186
SHOOTING MODE	186
MOVIE MODE	187
BACKGROUND DEFOCUS MODE	188
HIGH SPEED REC	189
 SELF-TIMER	190
MEDIA REC SETTING	190
HDMI OUTPUT SETTING	193
FIX MOVIE CROP MAGNIFICATION	194
F-Log/HLG RECORDING	195
DATA LEVEL SETTING	196
 PHOTOMETRY	196
 FLICKERLESS S.S. SETTING	196
 IS MODE	197
 IS MODE BOOST	197
 ISO	197
ZEBRA SETTING	198
ZEBRA LEVEL	198
MOVIE OPTIMIZED CONTROL 	199