

## Sensitivity

Adjust the camera's sensitivity to light.

Sensitivity settings can be displayed by pressing the **Fn** button to which sensitivity is assigned.

Option	Description
<b>AUTO1</b> <b>AUTO2</b> <b>AUTO3</b>	Sensitivity is automatically adjusted in response to shooting conditions according to combination of standard and maximum sensitivity and minimum shutter speed chosen for <b>SHOOTING SETTING &gt; ISO</b> . Choose from <b>AUTO1</b> , <b>AUTO2</b> , and <b>AUTO3</b> (107).
<b>80–12800</b>	Adjust sensitivity manually. Selected value is shown in display.
<b>L</b> (40) <b>H</b> (25600/51200/102400)	Choose for special situations. Note that mottling may appear in pictures taken at <b>H</b> , while <b>L</b> reduces dynamic range.



- Sensitivity is not reset when the camera is turned off.
- If desired, you can use **FUNCTION/DIAL SETTING > COMMAND DIAL SETTING** to configure the camera so that ISO sensitivity can be adjusted using the front or rear command dial.

### Adjusting Sensitivity

High values can be used to reduce blur when lighting is poor, while lower values allow slower shutter speeds or wider apertures in bright light; note, however, that mottling may appear in pictures taken at high sensitivities.