







The Playback Menu

Adjust playback settings.

 See page 220 for details.

 PLAY BACK MENU	
SWITCH SLOT	220
RAW CONVERSION	221
HEIF TO JPEG/TIFF CONVERSION	223
1/3 ERASE	224
SIMULTANEOUS DELETE	226
CROP	226
RESIZE	227
PROTECT	228

 PLAY BACK MENU	
IMAGE ROTATE	229
VOICE MEMO SETTING	230
RATING	231
2/3 COPY	232
TRANSFER IMAGE TO SMARTPHONE	233
 WIRELESS COMMUNICATION	235
DESQUEEZE DISP. IN PLAYBACK	235
PHOTOBOOK ASSIST	236
PRINT ORDER (DPOF)	238
3/3 instax PRINTER PRINT	239
DISP ASPECT	240