














## Setup Menu

Adjust basic camera settings.

 See page 271 for details.

 USER SETTING		 SCREEN SETTING	
<b>FORMAT</b>	272	<b>VIEW MODE SETTING</b>	282
 <b>AREA SETTING</b>	273	<b>EVF BRIGHTNESS</b>	282
<b>DATE/TIME</b>	273	<b>EVF COLOR</b>	282
<b>TIME DIFFERENCE</b>	274	<b>EVF COLOR ADJUSTMENT</b>	283
 <b>言語/LANG.</b>	275	<b>LCD BRIGHTNESS</b>	284
 <b>MY MENU SETTING</b>	275	<b>LCD COLOR</b>	284
 <b>MY MENU SETTING</b>	275	<b>LCD COLOR ADJUSTMENT</b>	284
<b>SENSOR CLEANING</b>	276	<b>IMAGE DISP.</b>	285
<b>BATTERY AGE</b>	276	<b>AUTOROTATE DISPLAYS</b>	285
<b>RESET</b>	277	<b>PREVIEW EXP./WB IN MANUAL MODE</b>	286
<b>REGULATORY</b>	277	<b>NATURAL LIVE VIEW</b>	286
<b>SOUND SETTING</b>		<b>F-Log VIEW ASSIST</b>	287
<b>AF BEEP VOL.</b>	278	<b>ELECTRONIC LEVEL SETTING</b>	287
<b>SELF-TIMER BEEP VOL.</b>	278	<b>FRAMING GUIDELINE</b>	288
<b>OPERATION VOL.</b>	279	<b>AUTOROTATE PB</b>	289
 <b>REC START/STOP VOLUME</b>	279	<b>FOCUS SCALE UNITS</b>	289
<b>MS EF ELECTRONIC SHUTTER VOLUME</b>	279	<b>APERTURE UNIT FOR CINEMA LENS</b>	289
<b>MS EF ELECTRONIC SHUTTER SOUND</b>	280	<b>DUAL DISPLAY SETTING</b>	290
<b>ES ELECTRONIC SHUTTER VOLUME</b>	280	<b>DISP. CUSTOM SETTING</b>	290
<b>ES ELECTRONIC SHUTTER SOUND</b>	280	<b>LARGE INDICATORS MODE(EVF)</b>	291
<b>PLAYBACK VOLUME</b>	281	<b>LARGE INDICATORS MODE(LCD)</b>	291
<b>4ch AUDIO PLAYBACK</b>	281	<b>LARGE INDICATORS DISP. SETTING</b>	292
		<b>INFORMATION CONTRAST ADJ.</b>	292
		<b>LOCATION INFO</b>	293
		 <b>Q MENU BACKGROUND</b>	293
		 <b>Q MENU BACKGROUND</b>	293