

Network/USB Setting Menus	313
CREATE/EDIT CONNECTION SETTING.....	313
SELECT CONNECTION SETTING	318
AIRPLANE MODE	319
Bluetooth/SMARTPHONE SETTING.....	320
instax PRINTER CONNECTION SETTING.....	323
Frame.io Camera to Cloud.....	323
FTP OPTIONAL SETTING.....	326
USB POWER SUPPLY/COMM SETTING	328
INFORMATION	329
RESET NETWORK/USB SETTING	329

9 The Setup Menus 331

USER SETTING	332
FORMAT.....	332
🏠 AREA SETTING.....	333
DATE/TIME	333
TIME DIFFERENCE.....	334
🗣️ 言語/LANG.	335
📷 MY MENU SETTING.....	335
👤 MY MENU SETTING.....	335
SENSOR CLEANING	336
BATTERY AGE	336
RESET	337
REGULATORY.....	337
SOUND SETTING.....	338
AF BEEP VOL.	338
SELF-TIMER BEEP VOL.	338
OPERATION VOL.....	339
🔊 REC START/STOP VOLUME.....	339
MSEF ELECTRONIC SHUTTER VOLUME	339
MSEF ELECTRONIC SHUTTER SOUND	340
ES ELECTRONIC SHUTTER VOLUME.....	340
ES ELECTRONIC SHUTTER SOUND	340
PLAYBACK VOLUME	341
4ch AUDIO PLAYBACK.....	341