


SENSOR CLEANING	276
BATTERY AGE	276
RESET	277
REGULATORY	277
SOUND SETTING	278
AF BEEP VOL.	278
SELF-TIMER BEEP VOL.	278
OPERATION VOL.	279
 REC START/STOP VOLUME	279
MEF ELECTRONIC SHUTTER VOLUME	279
MEF ELECTRONIC SHUTTER SOUND	280
ES ELECTRONIC SHUTTER VOLUME	280
ES ELECTRONIC SHUTTER SOUND	280
PLAYBACK VOLUME	281
4ch AUDIO PLAYBACK	281
SCREEN SETTING	282
VIEW MODE SETTING	282
EVF BRIGHTNESS	282
EVF COLOR	282
EVF COLOR ADJUSTMENT	283
LCD BRIGHTNESS	284
LCD COLOR	284
LCD COLOR ADJUSTMENT	284
IMAGE DISP.	285
AUTOROTATE DISPLAYS	285
PREVIEW EXP/WB IN MANUAL MODE	286
NATURAL LIVE VIEW	286
F-Log VIEW ASSIST	287
ELECTRONIC LEVEL SETTING	287
FRAMING GUIDELINE	288
AUTOROTATE PB	289
FOCUS SCALE UNITS	289
APERTURE UNIT FOR CINEMA LENS	289
DUAL DISPLAY SETTING	290
DISP. CUSTOM SETTING	290