










 BUTTON/DIAL SETTING		
	FOCUS LEVER SETTING	294
	 EDIT/SAVE QUICK MENU	295
	 EDIT/SAVE QUICK MENU	295
	FUNCTION (Fn) SETTING	295
1/3	POWER ZOOM LENS FUNCTION (Fn) SETTING	295
	SELECTOR BUTTON SETTING	295
	COMMAND DIAL SETTING	296
	 S.S OPERATION	297
	COMMAND DIAL DIRECTION	297
	SHUTTER AF	298
	SHUTTER AE	298
2/3	SHOOT WITHOUT LENS	299
	SHOOT WITHOUT CARD	299
	LENS ZOOM/FOCUS SETTING	300
	AE/AF-LOCK MODE	302
	AWB-LOCK MODE	302
	APERTURE RING SETTING (A)	303
	APERTURE SETTING	303
3/3	 Fn1 BUTTON SETTING	303
	TOUCH SCREEN SETTING	304
	LOCK	305

 POWER MANAGEMENT		
	AUTO POWER OFF	306
	PERFORMANCE	306
	EVF/LCD BOOST SETTING	307
	AUTO POWER OFF TEMP.	307

 SAVE DATA SETTING		
	FRAME NO.	308
	EDIT FILE NAME	309
	 CARD SLOT SETTING	309
	SELECT SLOT ( SEQUENTIAL)	309
	SELECT FOLDER	310
	COPYRIGHT INFO	310
	GEOTAGGING	310