

The DISP/BACK Button

The **DISP/BACK** button controls the display of indicators during playback.

